

KNOW SLACK-JACK™

Installation Instructions

Installation Instructions



Check Approved Plans for Locations To Install SlackJack™ Device(s).

Verifique los planos autorizados para instalar el SlackJack™.



Place Color-Coded Bearing Plate.

Coloque el plato de compresión. El color que el plano te indique.



Drop SlackJack™ Over Rod.

Deje caer el SlackJack™ sobre el tornillo.

US PATENTS: 7,762,030; 7,665,258; 7,617,642; 7,340,867; 7,159,366; 6,951,078; 6,688,058; 6,494,654; 6,161,350

KNOW SLACK-JACK™

Installation Instructions



Install Color-Coded Swivel Washer (Flat Side UP).

Instale la rondana de color con la parte plana hacia arriba.



Install Hex Nut.

Instala la tuerca exagonal y apriete con la mano.



Tighten Hex Nut by Hand. No Tools Required.

Para apretar la tuerca exagonal no requiere herramienta.

US PATENTS: 7,762,030; 7,665,258; 7,617,642; 7,340,867; 7,159,366; 6,951,078; 6,688,058; 6,494,654; 6,161,350

KNOW SLACK-JACK™

Installation Instructions



Using Two Hands, Remove Pull Clip to Activate the SlackJack™ Device. Grip Device with One Hand and Pull Clip With Other.

Para activar el dispositivo SlackJack use las dos manos y remueva el perno o clip. Sujete el dispositivo con una mano y remueva el perno o clip con la otra.



Ensure Pull Clip is Completely Removed.

Asegurese que el perno o clip este completamente removido.



Store Pull Clip as Shown for Inspection Verification.

Guarde el perno o clip como se muestra para inspección.

US PATENTS: 7,762,030; 7,665,258; 7,617,642; 7,340,867; 7,159,366; 6,951,078; 6,688,058; 6,494,654; 6,161,350

KNOW SLACK-JACK™

Installation Instructions

Completed Installation (typical)

Instalación Completa (Típica)

Rod Size	Swivel Washer Color
R-4	Purple (Morado)
R-5	Black (Negro)
R-6	Grey (Gris)
R-7	Blue (Azul)
R-8	Yellow (Amarillo)
R-9	White (Blanco)
R-10	Green (Verde)
R-12	Red (Rojo)



****If Required: Add Coupler and Rod Until Top Level Has Been Reached****

Si se requiere mueva el cople sobre la rosca hasta que se alcance el nivel mas alto.

****Store Pull Clip for Inspection.****

This Will Confirm the Device Has Been Properly Activated.

Guarde el perno o clip para inspección.

Esto asegura que el dispositivo ha sido activado apropiadamente.

SlackJack™ Extension	Color
1"	Red (Rojo)
2"	Green (Verde)

Bearing Plate	Color
P-8	Black (Negro)
P-10	Blue (Azul)
P-12	Grey (Gris)
P-14	Red (Rojo)
P-18	Yellow (Amarillo)